

Equi-Vue2™ USER MANUAL (V2)

INTRODUCTION:

Thank you for purchasing our Equi-Vue2™ wi-fi camera. This User Manual includes information about how to correctly use the camera and product information, including operation, installation and technical specifications. Please read the User Manual carefully before using/installing the camera.

SPECIFICATIONS:


Battery capacity	2100mAh
Battery voltage	3.7V
Recharge time	Approx 4.5 h
Recharge voltage / current	5V / 480mA (Max)
Operating current	260mA
Wireless communication	Wi-Fi / 2.4Ghz
Wireless transfer distance	15m line of sight
Water Resistance	IP68
Night Vision	IR (6)
Lens Angle / Resolution	120° / 700TV Lines (Non Mirror Image)
Operating Temperature	-20°C to +70°C



CHARGING THE CAMERA:

1. Remove the orange cover by gently pulling it from the rear of the camera.
2. Insert the charging lead and connect to a USB adapter (the LED will illuminate Red when charging)
3. The camera will fully charge in approx. 4.5 hours & then LED will be off.

ICON DESCRIPTIONS:



INSTALLATION:

1. Choose a suitable location for the camera, high up on a wall, as far from the horse(s) as possible, usually provides the best view (hold the camera in the chosen location & check the view, before fixing).
2. The camera includes a magnet and can be easily 'fixed' to any metal work (be careful to check that the fixing location is magnetic, before letting go of the camera).
3. A velcro fixing square is also provided, please utilise on a wall (not roof) and ensure the chosen location is clean/dry (so that the glue can achieve a good bond).

OPERATION (Android):

1. Download/install the 'Safetycam' App from Google Play:



2. Turn the camera on, by pressing the button on the front (the blue LED will illuminate).
3. Open 'Settings' / 'Wi-Fi' and select 'SONIX_' (ignore any message about no Internet connection etc).
4. Open the Safetycam App.
5. If the camera image/view is not displayed please check that 'Location Services' in Settings/App Settings is turned on.

OPERATION (Apple/iOS):

1. Download/install the 'Safetycam' App from the App Store or use the following QR code:



2. Turn the camera on, by pressing the button on the front (the blue LED will illuminate).
3. Open 'Settings' / 'Wi-Fi' and select 'SONIX_' (ignore any message about no Internet connection etc).
4. Open the Safetycam App and the camera image will be displayed.
5. If the camera image/view is not displayed please check that 'Location Services' in Settings/App Settings is turned on.

To RESET the Camera:

1. Turn the Camera on and leave it switched on until the power LED extinguishes.
 2. Turn the Camera off.
 3. Charge the Camera for at least 8 hours / overnight.
- (This process also 'conditions' the battery).

For Technical Support please email:

support@trailervision.co.uk

Or, during office hours please call: **01733 246473**