




QUICK START GUIDE

V1 Jun19

System Contents:





Note: For video recording, ENSURE that a CLASS 10 memory card or above (8GB supplied) is utilised, as other kinds of memory card may cause unexpected results and should be avoided.

SETTING UP THE CAMERA

1. APP DOWNLOAD

Please download and install the "OMGuard HD" APP to




2. Power the camera

Plug the camera in to a mains supply, via the supplied power adapter, and check that the Red & Green LEDs are flashing, which indicates the camera is ready for Wi-Fi setup. This process should be completed within 1min; ensure that both LEDs are flashing Red & Green.

Note: If the LEDs are not flashing, Red & Green, press and hold the reset button for 5 seconds until the Red & Green LEDs start to flash.


3a. Direct Wireless Connection:

(1) Go to the Wi-Fi setting on your mobile device. Choose the Wi-Fi router with a prefix of HD-xxxxxx (xxxxxx = Camera ID numbers). Enter the **default password 12345678** and 'save' the settings.

- (2) Launch the APP, tap  to add the camera.
- (3) Tap (QR code icon) and scan the QR code label on the back of the camera to bring up the DID information. Or tap "search" and select the camera DID (also printed on the camera label).
- (4) Enter the **default password 123456** and 'save' the settings.



3b. Alternatively, establish a connection via the Ethernet cable:



- (1) Connect your mobile device to the Wi-Fi router. Connect the camera to the Wi-Fi router with the supplied Ethernet cable. After powering the camera, it will take approx 40 seconds to connect to the router. When completed/connected the green LED will stay ON.
- (2) Launch the APP, tap the "Search" button to locate the camera.
- (3) Enter the default password **123456** then 'save' the settings.

4. Wi-Fi Setting




- 4b. The camera will be offline for around 40 seconds to reboot for Wifi connection. When the camera connects to the Wi-Fi router correctly, the Green LED will stay ON.
- 4c. In the Wi-Fi settings of your smart phone/tablet, make sure that the Wi-Fi router you are connecting to is the same one as the camera. If not, manually connect to it.


Note: Be sure to choose your local home Wi-Fi router on your local network in the App ADVANCED SETTINGS. The system will begin to count down and reboot the system. The camera view will show on screen again after the Wi-Fi setting has been updated.

Note: Wi-Fi setting may fail if you leave the ethernet cable connected. Please remove the cable after settings have been completed.

CAMERA INSTALLATION




Note: Ensure that the camera is located in an area of Wi-Fi signal/reception.



LIVE VIEW / SNAPSHOT / PLAYBACK




FACTORY DEFAULT SETTING


Press and hold the reset button on the power cable for 5 seconds and the system will start the reset process. The system will restore to factory default and you may start the Wi-Fi setup.




For further information please email:
support@trailervision.co.uk

Follow the steps below for Event Playback.


1. Tap  and then the .
2. Select the time interval for the event list.
3. Tap to select the file for playback.
4. To store the files in the mobile device,  to download (best when connected to Wi-Fi or a 4G network due to large file/data size).



FCC Compliance Statement: This device complies with Part 15 of the FCC rules. Operation is subjected to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Products with CE Marking comply with EMC Directive (2014/30/EU); Low Voltage Directive (2014/35/EU); RED (2014/53/EU); ROHS Directive (2011/65/EU) issued by the Commission of the European Community. Compliance with these directives implies conformity to the following European Norms:
EMC: EN 301 489
LVD: EN 60950
Radio: EN 300 328



If the camera system no longer functions or can no longer be repaired, it must be disposed of according to the valid statutory regulations. Disposal of spent batteries/accumulators:
You are required by law (Battery Ordinance) to return all spent batteries and accumulators. Disposing of spent batteries/accumulators with common household waste is prohibited! Batteries/accumulators that contain hazardous substances are marked with the symbols on the side. These symbols indicate that it is prohibited to dispose of these batteries/accumulators in the household waste. The abbreviations for the respective heavy metals are: Cd=cadmium, Hg=mercury, Pb=lead. You can return spent batteries and accumulators that can no longer be charged to the designated collection points in your community, outlets or wherever batteries or accumulators are sold. Following these instructions will allow you to fulfill the legal requirements and contribute to the protection of our environment!